

Updating Insight® Software

For R8, R9, R10 & R11

Load a USB flash stick (FAT) with new software files from <https://headsight.com/manuals> technical info->Insight Software.

Unzip, and then copy insightf.hex in the root directory (ex. D:\insightf.hex)

- Do not change file name

Plug USB stick into USB port on the Insight box on the header.

- Remove USB cap

Power Insight.

- Connect all wiring to combine
- Turn on key switch

Wait for software to flash.

- Yellow light will blink while download is in progress
- Green light will turn on solid when download is complete

Verify update is successful.

- Go to >>About Insight>>Software Version and read software version number

Remove power from Insight.

- Turn off key

Remove USB stick.

- Replace USB cap

For R7

Updating software may cause the Foresight option to be disabled. If you have purchased Foresight, contact Headsight before updating software.

We can also update for you, contact Headsight for details.

You need:

SD memory card (2GB or less, FAT format preferred)

Means of loading SD memory Card: computer with SD card drive, SD/usb memory adapter, or preloaded SD memory card from Headsight

Small allen wrench or screwdriver

Load SD card with new software files from <https://headsight.com/manuals> technical info->Insight Software. Place insightf.hex in the root directory of SD card (ex. E:\insightf.hex)

- Do not change file name

Power down and remove insight from the machine, remove rear cover.

Insert programmed SD card into SD card slot on rear of board.

Power Insight.

- Connect all wiring to combine
- Turn on key switch

Wait for software to flash.

- Yellow light will blink while download is in progress
- Green light will turn on solid when download is complete

Verify update is successful.

- Go to >>About Insight>>Software Version and read software version number

Remove power from Insight.

- Turn off key

Remove SD card.

Reinstall rear cover, make sure seal is clean!