

R5 HW and later are supported

Changes from 4.16 -> 4.18

Support for Rev12 hardware.

Simplified support for one sensor systems.

Added support for NH TX & TC "dot" machines.

UI improvements.

Updated phone number to 574-220-5511.

Change from 4.14 -> 4.16

Fixes a bug that could set the wrong box revision. **Boxes on 4.10 - 4.14 need to update.**

Changed minimum sensor voltage to .33V from .30V for consistency with Horizon.

Change from 4.11 -> 4.14

Digital out 22 could get set low periodically.

Translation updates, menu item clarity.

Change from 4.10 -> 4.11

Fixes a bug with JD DAM and AGCO setup menus.

Changes from 4.01 -> 4.10

Support for Rev10 hardware.

Added Driver Test and Signals Page to "Detailed Diagnostics"

- Pre Rev10 will only display p23 & p24 with no voltage readback. Will still turn on output.
- Pre Rev10 has fewer Signal readbacks, but still handy.
- Rev 10: p04 and p05 are both VBAT for more current capacity, readback for p04 is VBAT for p05 is 12V regulator

Redesigned "Disp Sensor Voltage" to "Display Voltage" now includes output voltages as well as the sensor inputs.

Added Raise/Lower arrows to Outputs on "Display Voltage" for DAM and Gleaner.

Added Support for CIH HILLCO

Model Updates, misc. text and translation updates.

Update to build codes and new MPB shortcut.

Better decimal rounding.

Fixed some issues where the checkmark did not appear when on saved setup.

Cut Foresight Ranges from the Engineering menu.

Memory Improvements.